- 1. Locate a flat and level install location on your wall. We recommend mounting the hinge side holes over a wall stud.
- 2. Align the template with the hinge side holes over wall stud location. Use a level and tape paper template in place.
- 3. Use a 1/8" drill bit and drill ( ) pilot holes on all markings on the
- anchors as needed. Stud mount locations will NOT require anchors and
- 5. Open the canvas and mount the backplate to the wall using included #8 x 1-1/4" screws in all pre-drilled locations. (Recommend additional
- 6. Remove the rubber cap and use the supplied key magnet on the outside of your canvas to operate the hidden lock. To keep unlocked,
  - 7. To install Grid-It organizer, place in desired location and attach directly to backplate, through mounting grommets, with supplied #6 screws. To install the rubber coated ring magnets, place in desired location and attach using #6 screws. The nylon washers can be used to bump out the magnets when using a revolver to clear the cylinder. Do
- 8. Adjust the hinges so the canvas does not scrape your wall. If you are having problems with alignment and/or lock, adjust the hinges as needed.
  - 9. For Landscape Top Hinge, use supplied Allen wrench to tighten lift flap stays until canvas will stay open on its own. **Never stand directly** under the canvas in the open position as it may fall and cause harm.

For more information please visit our website, YouTube Channel or contact us directly at info@concealcanvas.com.



Lock Support Hole - Wall anchor location (pre-drill using 1/8" drill bit)















SIHT

LEFT HINGE

FOR



Grey box represents backer plate. Use outline for leveling.