

THIS SIDE UP FOR LANDSCAPE, TOP HINGE

HINGE SIDE

Recommended stud mount location (pre-drill using 1/8" drill bit)

Recommended stud mount location (pre-drill using 1/8" drill bit)

16" on center for landscape stud mounting if possible

16" on center for landscape stud mounting if possible

# CONCEAL CANVAS

Installation Template - Delta

THIS SIDE UP FOR RIGHT HINGE

THIS SIDE UP FOR LEFT HINGE

### Tools Required:

- Tape
- Level
- Drill
- 1/8" Drill Bit

### Optional Tools:

- Stud Finder

### Hardware Included:

- (10)Qty - #8 x 1-1/4" Screws
- (10)Qty - #8 Nylon Wallboard Anchors
- (3)Qty - 1-3/8" Stud Screws
- (1)Qty - Grid-It Organizer or (3)Qty - Ring Magnets or (2)Qty - Hanging Hooks w/ straps
- (4)Qty - #6 x 1" Screws
- (6)Qty - Nylon Spacing Washers
- (1)Qty - Key Magnet for Locking Pin

### Installation Steps:



1. Locate a flat and level install location on your wall. We recommend mounting the hinge side holes over a wall stud.



2. Align the template with the hinge side holes over wall stud location. Use a level and tape paper template in place.



3. Use a 1/8" drill bit and drill (⊕) pilot holes on all markings on the template.



4. Remove template from wall and install included nylon wallboard anchors as needed. Stud mount locations will NOT require anchors and you should screw directly into the wall stud.



5. Open the canvas and mount the backplate to the wall using included #8 x 1-1/4" screws in all pre-drilled locations. (Recommend additional help holding canvas to install)



6. Remove the rubber cap and use the supplied key magnet on the outside of your canvas to operate the hidden lock. To keep unlocked, place rubber cap back on locking pin.



7. To install Grid-It organizer, place in desired location and attach directly to backplate, through mounting grommets, with supplied #6 screws. To install the rubber coated ring magnets, place in desired location and attach using #6 screws. The nylon washers can be used to bump out the magnets when using a revolver to clear the cylinder. Do not overtighten. To install hooks, pre-drill desired location with 1/8" drill bit and hand screw hooks in. Use Velcro straps for extra security.


8. Adjust the hinges so the canvas does not scrape your wall. If you are having problems with alignment and/or lock, adjust the hinges as needed.

9. For Landscape Top Hinge, use supplied Allen wrench to tighten lift flap stays until canvas will stay open on its own. **Never stand directly under the canvas in the open position as it may fall and cause harm.**

For more information please visit our website, YouTube Channel or contact us directly at [info@concealcanvas.com](mailto:info@concealcanvas.com).



Follow us on Social Media - @concealcanvas



Lock Support Hole - Wall anchor location (pre-drill using 1/8" drill bit)

Grey box represents backer plate. Use outline for leveling.

Wall anchor location (pre-drill using 1/8" drill bit)